



## STEP 1\_

Begin by **prying the glass** from the mirror using a suitably sized trim removal tool. The glass should pop out with moderate force and be free from the clamp. **DO NOT** pull the mirror glass too far from the clamp as the two heater wires will remain attached.

## STEP 2\_

Locate the two wires and **remove by pulling on the connector**. These wires can be re-installed either way but it is always good practice to remember how they were connected. Once removed, the mirror glass is free and can be carefully set aside for later.



## STEP 3\_

Now locate the **three upper tabs** at the inner top-side of the mirror unit. These should be manipulated to release the top edge of the mirror cap and allow it to be teased away from the unit itself. It's handy to have two removal tools to hand and use one to slide between the cap and the unit.

## STEP 4\_

To **completely remove the mirror cap**, work your way around the outer edge with a trim removal tool or your fingers and begin **prying the bottom edge** away from the assembly. These tabs can be broken so it's best to take your time and care without forcing the plastic.

**CONTINUED...**



## STEP 5\_

Next, locate the **two Torx 10** screws that hold the lower cap securely in place. These should come out with ease and **must be saved for the installation** of the new cap. Make sure to support the cap on removal of the screws as to not let it drop away from the assembly.

## STEP 6\_

Carefully lower the mirror caps away from the assembly being careful to **follow the plane of the mirror arm**. You may have to manipulate the cap in certain areas as some tabs tend to catch when lowering. Now is a great opportunity to **clean any dust and dirt** from the unit.



## STEP 7\_

The installation of the lower mirror cap is the **opposite of removal**. Take extra care when introducing it to the mirror assembly as gloss finishes are susceptible to scratches and some of the tabs can be quite delicate. Again, support the cap once in place and **insert the two Torx 10 screws**. You'll feel some resistance here as the bite into the plastic but this is entirely normal.

## STEP 8\_

To complete the installation, **ensure the DAB antenna is placed over the tabs** as pictured above. Once you've checked everything is secure, re-install your upper mirror cap following the same process you used to remove it. Finish the job by **squeezing both the upper and lower caps together** until everything has clicked into place. Finally, re-connect your two glass wires and press firmly into place with even force.