VANSTYLE

Unit 1
Bilsthorpe Business Park
Bilsthorpe
Nottinghamshire
NG22 8ST

STEP 1_

Begin by **prying the glass** from the mirror using a suitably sized trim removal tool. The glass should pop out with moderate force and be free from the clamp. **DO NOT** pull the mirror glass too far from the clamp as the two heater wires will remain attached.

STEP 2_

Locate the two wires and **remove by pulling on the connector**. These wires can be re-installed either way but it is always good practice to remember how they were connected. Once removed, the mirror glass is free and can be carefully set aside for later.

STEP 3_

Now locate the **three upper tabs** at the inner top-side of the mirror unit. These should be manipulated to release the top edge of the mirror cap and allow it to be teased away from the unit itself. It's handy to have two removal tools to hand and use one to slide between the cap and the unit.

STEP 4_

To **completely remove the mirror cap**, work your way around the outer edge with a trim removal tool or your fingers and begin **prying the bottom edge** away from the assembly. These tabs can be broken so it's best to take your time and care without forcing the plastic.

Installation is the reverse of removal.

VW T5/T6 - WING MIRROR COVER REPLACEMENT